

1. Put metal cover 1, diffuser and the shade in the frame, place the metal cover 2 on the shade
3. Put the small cover under the frame, then secured all the above parts together by the nipple ad finial

