

1. Attached the top arm on the nipple then secure by tube 1.
2. Attached the tube 2 on the socket.

