



## Assembly Instruction For 21127

1. Spread the arms evenly, make sure each arm is aligned with the center rod.
2. Turn the nipple into the coupler 1.
3. Attach the poly column on the nipple then secured by the loop.
4. Attach the arm combination to the center rod by the nipple 1 then secured by the finial ball.
5. Turn the nipple 2 into the coupler 2.
6. Attach the cap on the nipple 2 then secured by the hex nut.
7. Screw the finial on the nipple 2.
8. Attach the glass on the socket then secured by the socket ring.

