

# MAXIM Assembly Instruction For 21346

1. Put cap(B), tube(C) and cap (S) on nipple(D), then secured by the loop(A)
2. Through the nipple(E), cap(F) round metal (G), and notch cap(H), then lock the ball (I) to the nipple (E)
3. Through the nipple(J), cap(K) round metal (L), and notch cap(O), then lock the ball (R) to the nipple (J)
4. Place the metal shade(M), glass shade(W), metal ring(Q) on the socket (N) then secured by socket ring(P)
5. Insert the G9 bulbs into socket (N) one by one

