

Assembly Instruction For 22265

- 1. Spaced the arms level
- 2. Thread the nipple to the coupler then fix it by Hex nut1
- 3. Attach the cover and poly column to the nipple, then secure by loop
- 4. Thread the nipple 2 to the coupler 1, then cover 1 to the nipple 2, then secure by finial
- 5. Thread the nipple 3 to the poly column 1 then secure by finial 1
- 6. Hang the crystals to the rings of the arm
- 7. Attach the glass to the sockets then secure by socket ring

