

1. Screw the tube ( B ) to the tube ( A ) till tight.
2. Screw the tube ( G ) to the tube ( B ) till tight.
3. Screw the tube ( D ) to the tube ( G ) till tight.
4. Screw the tube ( E ) to the tube ( D ) till tight.
5. Attach the the canopy ( G ), metal sheet ( H ) and washer ( I ) then secure by hex nets ( J ).
6. Place the glasses ( M ) over the sockets ( N ) then secure by socket rings ( L ).
7. Attach the shades ( K ) to the glasses ( M ) and make it is level.

