

MAXIM Assembly Instruction For 24165SBUB

1. The nut(L) is through metal washer(K), cross spider (J), fabric shade(I), aluminum shade(H) and cap(G); then secured by ball(F) till tight
2. Secured the poly body(B) with the cross spider(J) together
3. Put the arm component(A) on the cross spider(J), then secured by two side balls(C) till tight
4. Secured the finial(E) to the nipple(D) till tight
5. Install 6*60W type B bulbs into socket of this fixture(Bulbs not included)

