



Install the collar at the top and bottom, use the nuts to stable the wire guard, tighten the aluminium ring with the coupler.